

Existing Product	Seajet 031 Samurai, Seajet 033 Shogun, Seajet 034 Emperor, Seajet 036 Shogun-Eco	Seajet 039 Platinum	Seajet 037 Coastal
Boero Altura 619 (without Regaflon/PTFE)	1	2	1
Boero Corsa 642 (without Regaflon/PTFE)	1	2	1
Boero Corsa Regatta 619 (without Regaflon/PTFE)	1	2	1
Boero Mistral 633 (without Regaflon/PTFE)	1	2	1
Boero Scirocco 622	1	2	1
Compass Antifouling (all types)	1	2	1
Gold Label	1	2	1
Hard Antifouling	1	2	1
Hempel Bravo	1	2	1
Hempel Broads	1	2	0
Hempel Combic	1	2	1
Hempel Cruising Performer/Tiger Cruising	0	2	0
Hempel Globic	1	2	1
Hempel Hard Racing	1	2	1
Hempel Hard Racing Ultra	3	3	1
Hempel Mille	0	2	0
Hempel Ocean Performer	0	2	0
Hempel Oceanic	1	2	1
Hempel Olympic	1	2	1
Hempel Tiger Extra/Titan Ultra	0	2	0
International Micron 55/66	0	2	0
International Uni-Pro	1	2	1
International VC17M	3	3	3
International Boatguard	1	2	0
International Cruiser Premium/Uno	0	2	0
International Interspeed Ultra	1	2	0
International Micron Extra/CSC	0	2	0
International Optima	0	2	0
International Superyacht 800/900	0	2	0
International Trilux	1	2	0
International VC Offshore	1	2	1
International Waterways	1	2	0

Jotun Marenostrom	1	2	0
Jotun Non Stop	0	2	0
Jotun Super Tropic	1	2	0
Nautix A2	0	2	0
Nautix A3	1	2	0
Nautix A3 T. Speed	3	3	3
Nautix A4	1	2	1
Nautix A4 T. Speed	3	3	3
Nautix Marine	1	2	1
Niemeyer/van. Höveling	1	2	1
Plastimo Classic	0	2	0
Plastimo Performance	0	2	0
Plastimo Racing	0	2	0
Seajet 031 Samurai / 033 Shogun / 034 Emperor	0	2	0
Seajet 039 Platinum	0	0	0
Seajet 037 Coastal / 030 Warrior	0	2	0
Seajet Speed Finish	3	3	3
Sikkens Chloorrubber 2000	1	2	1
Soft Antifouling	2	2	2
Soromap AF1	1	2	1
Soromap AF2	1	2	1
Soromap AFC+	1	2	1
Stopmar (Stoppani)	1	2	
Stoppani Fisher	1	2	1
Stoppani Noa Noa Rame	1	2	1
Stoppani Noa Noa Rame autopolissant	1	2	1
Stoppani Sibelius	1	2	1
Stoppani Sibelius H.M.	1	2	1
Stoppani Sintofouling Rame	1	2	1
Teflon Antifouling	3	3	3
Tin-Based SPC Antifouling	0	2	0
Unknown Antifouling	2	2	2
Waterline	2	2	2
XM C2000 Eroding	1	2	0
XM HS3000 Eroding	1	2	0
XM P4000 Hard	2	2	0

0 - Apply antifouling after removing slime or fouling with high pressure fresh water, remove loose antifouling and spot repair with the recommended primer.

1 - As above but light wet-sanding of the existing antifouling is required, then rewash before painting.

2 - As above but apply a barrier coat of Seajet 011 Underwater Primer before applying the new coating.

3 - Remove the existing anti-fouling and apply the recommended primer system before applying anti-fouling.

Don't take any risks! Remove existing anti-fouling in poor condition.